The same of the sa

A.

A. Preventine measures need to be taken for pollution free environment:

- 2) Wrap construction area/buildings with geotextile fabric installing dust parriers, or other actions, as
- b) Apply water undisministrain soils in a visible damp or coursed condition for temporary stabilization.
- c) Apply water patter to leveling or any other earth-moving activity to keep the soil moist throughout the d) Limit withing spension to 15 mpb on the work site.

 e) Clean felicult and undercorriage of hadd trucks orior to leaving construction site.

 - Apply and maintainedust suppressant ob half poutes.
 - g) Apply a cover an assess to stockpiles and stabilize stockpiles at completion of activity by water and maintain a disall millimitive to all cutter surfaces of the stockpiles;
- h) Stabilize surface milk where loaders, support equipment and vehicles will operate by using water and maintake startings amils in a stabilized condition where loaders, support equipment and vehicles will
- fi Stabilize adjaceme disturbed soils following paving activities with immediate landscaping activity or
- il idaintain dust samural during working hours and clean track out from paved surfaces at the end of the work shiftisher. Truck out must now extend 50 feet or more and must be cleaned daily, at the mindmon.
- t: Stabilize slegging sturfaces using soil binders until vegetation or ground cover can effectively stabilize
- Disposal of details in consultation with the local authorities following proper environmental
- m) During construction work, including cutting of marbles, ambient noise level should not exceed more
- 8. Practices to be discarded for pollution free Emironment
- Don't dispose of dishrip indiscriminately,
 On't allow the weblicles to run at high speed within the work site. Don't cut materials without proper dust control/noise control facility. Don't keep materials without effective cover.
 - Don't allow access in the work area except workers to limit soll disturbance and prevent access by fencing, disches, wegespiton, herms or other suitable barrier. Don't leave the sed, sand and cement stack uncovered.
- Don't keep materials or debris on the roads or pavements.
- Burning of aid lines in hot mik plant as a fuel during construction and repair of the reads for melting

Office of the Executive Engineer, Br.-X Building Department, Br.-X

1 2012/2018

CEKTIFIED CUPT

Plan for Water Supply arrangement including SEMILI G. & O. H. reservoirs should be submitted at the Office of the Ex-Engineer Water Supply and the sanction obtained before proceeding with the work of Water Supply any deviation may lead to disconnection/demolition.

CONSTRUCTION SITE SHALL BE MAINTAINED TO PREVENT MOSQUITO BREEDING AS REQUIRED U/S 496 (1) & (2),OF CMC ACT 1980. IN SUCH MANNER SO THAT ALL WATER COLLECTION & PARTICULARLY LIFT WELLS, VATS, BASEMENT CURING SITES, OPEN RECEPTACLES ETC. MUST BE EMPITED COMPLETELY TWICE A WEEK.

Sanctioned By : Sel

211

Assistant Engineer (C-B) Br. No.....

Before starting any Construction the site must conform with the plans sanctioned and all theconditions as proposed in the plan should be fulfilled.

The validity of the written permission to execute the work is subject to the above conditions.

The sanction refers to the proposed portion shown in red and the Executive Engineers makes no admission as to the correctness of the plan.

Design of all Structural Members including that of the foundation should conform to Standards specified in the National Building Code of India

All Building Materials to necessary & construction should conform's to standered specified in the National Building Code of India.

Nacessary steps should be taken for the safety of the lives of the adjoining public and private properties during construction.

Non Commencement of Erection/ Re-Erection within Two Year will Require Fresh Application for Senction.

DEVIATION WOULD MEAN DEMOLITION

APPROVED
ON 03/12/2016

"≣å

9

A suitable pump has bible provided i.e. pumping unfiltered water for the distribution to the flushing cisterns and urinats in the building incase unfiltered rater from street main is not available.

The building materials that will be stacked on Road/Passage or Foot-path beyond 3-months or after construction of G. Floor, whichever is earlier may be seized forthwith by the K.M.C. at the cost and risk of the owner.

THE TOLKATA WHITECHAL CORPORATION

THE TOLKATA WHITECHAL CORPORATION

BUILDING PERMIT

AD IN TOLKATA WHITECHAL

Ex. Express I August

THE SANCTION IS VALIED UP TO 19/12/2013

Sanctioned subject to describion of existing structure to provide open space as per plan sefore construction is started

Emouthe Engineer (C

And Propose (C)

No rain water pipe should be fixed or discharged on Road of Footpath.

Drainage plan should be submitted at the Borough, Execution 5.

the Borough Executive Expreer's Office and the sanction obtained before proceeding with the drainage work.

iny unathorised construction done in deviation from the Sanaton Building permit and the Completion Plans liter issuance of this Completion Plans may cause revocation of the pupancy Certificate.

SILDING DEPAY

RESIDENTIAL BUILDING

CERTIFIED COPY

